

Roller Foot

This foot includes built-in rollers (one at the front of the foot, and 2 smaller ones on the underside of the foot) to help feed difficult-to-sew fabrics such as leather, suede and vinyl.

Machine Preparation

- Attach Roller Foot.
- Manually lead the thread from the needle through the opening of the foot, and then slip the thread under and behind the foot.
- Set machine for Straight Stitch.
- Set the stitch length for a medium-long to long setting.

Note: If the stitch setting is set too short, this could cause perforation of the leather vinyl or suede. It is recommended to first try the stitch on a scrap to test.

Sewing Instructions

1. Use double-faced (basting) tape to hold the fabric pieces together for sewing. This will help prevent either layer from slipping while sewing.
2. Place fabric under the presser foot. Lower the presser foot.
3. Sew, following the desired seam guide line. When sewing leather, suede or vinyl, the seam allowances can then be either topstitched down or glued (with fabric glue) for finishing purposes.

