


INSTRUCTIONS OF ADDITIONAL ACCESSORIES

412 41 12-01 Shank

When attaching the special accessory foot you should change the presser foot holder to the shank that is designed to fit the special accessory feet included in this package. This shank (presser foot holder) should be used with the following feet:

Fancy Trim Foot, Stitch in the Ditch Foot, Adjustable Bias Binder, Single Welt Cord Foot, and Braiding Foot, and Braiding Guide.



Machine Preparation

- Remove the presser foot holder (Position 35 from the instruction manual on page 5) that is mounted on your sewing machine upon delivery, by loosen the presser foot thumb screw (34).
- Put the special accessory shank on the presser foot bar. Pull the holder as far as it will go from bottom of presser bar.
- Tighten the presser foot thumb screw (34).

Sewing instructions

1. Follow the instructions for the special accessory foot you like to use.
-